



NOTE:
 1. BASEMENT WINDOW R.O. STARTS 1'-6" DOWN FROM TOP OF FOUNDATION
 R.O. 2'-10 1/4" W X 4'-5" H
 2. FRENCH DOOR R.O. 6'-0" X 6'-8"
 3. BEAM POCKETS 10 1/4" DEEP X 12" WIDE

BASEMENT & FOUNDATION PLAN
 1/4" = 1'-0" 1340SF